

**Phone:**

1.866.534.4696 Toll Free

**Websites:**

www.directdryers.com

www.ppedryers.com

www.bootdryer.com

**Email:**

direct@directdryers.com



**WILLIAMS**  
DIRECT DRYERS

**Free Your  
Experience**

**Product Factsheet**

**Williams H8**

*Wall Mount: Dries 8 Flight Helmets.*



**• Safe and Efficient Drying**

Direct Drying focuses a stream of air to the most difficult area of the PPE to dry. The warmed air is delivered at a safe temperature to protect sensitive fabrics and prolong equipment life.

**• Children’s Hospital of Philadelphia Qualitative Quantitative Case Study**

A 13 month study conducted in 2011 proved that continuous drying was 99.95% effective in controlling the pathogen load in flight helmets.

**• Pathogens Controlled by Continuous drying**

Bacillus, Alpha-hemolytic streptococci, Micrococcus, Coagulase-negative staphylococcus, Yeast, Gram-positive rods, Gram-negative rods, Corynebacterium and Streptococcus viridans.

**• Built-in Energy Management**

Depending on your drying requirements, air is either delivered at 10-15°F (6-8°C) above room temperature or at room temperature for more economical operation.

**Specifications**

12” wide x 18” deep x 77” high (300 x 460 x 1960) Nominal  
120V 4A - 400W Heat  
16ga welded steel construction - powder coated

\* Report available upon request

Williams Boot & Glove Dryers Inc. dba Williams Direct Dryers  
17665 - 66A Ave # 206  
Surrey BC  
Canada V3S 2A7

